



REPLACEMENT WIRING - ENGINE COMPT.

6. REPLACEMENT HARNESS TO BE ROUTED SAME AS ORIGINAL HARNESS.
7. WHEN THE REPLACEMENT HARNESS IS INSTALLED IT MUST BE COVERED WITH VARGLASS SLEEVE.  
JOINTS BETWEEN NEW SLEEVING AND ORIGINAL SLEEVING TO BE WRAPPED WITH GLASS TAPE.
8. INSTALL THE HEAT SHIELD PROVIDED BY S.B. 402

PRELIMINARY